

INSTALLATION AND MAINTENANCE



KB Eco2S Series Electronic Unit Heater



DANGER

ELECTRIC SHOCK OR FIRE HAZARD

READ ALL WIRE SIZING, VOLTAGE REQUIREMENTS AND SAFETY DATA TO
AVOID PROPERTY DAMAGE AND PERSONAL INJURY

The ECO2S KB series unit heaters offers an energy efficient 2-stage heating, with ECO mode that automatically uses the lowest wattage needed to heat the room, integrated fan only and timer modes, as well as a remote control for simple operation. Designed for use as primary or supplemental heat sources in warehouses, stores or large garages spaces. Includes universal wall/ceiling bracket for simple installation.

⚠ WARNING ⚠

READ CAREFULLY - Use the heater only as described in this manual. Any other use is not recommended and could result in fire, electric shock, and personal injury. Following these instructions will prevent difficulties that might occur during the installation and use of the heater. Please study the instructions first, as they may save considerable time and trouble during use addition to providing important safety information. Make sure to save these instructions for future use.

NEVER LEAVE HEATER UNATTENDED WHILE CONNECTED TO A POWER SOURCE

- ⚠ WARNING** To prevent a possible electrical shock, disconnect all power coming to heater at main service panel before wiring or servicing.
- ⚠ WARNING** All wiring must be in accordance with the National Electrical Code (Canadian Electrical Code in Canada) and all applicable local codes. The heater must be grounded as a precaution against electrical shock. Supply wiring must be copper and suitable for at least 75° C.
- ⚠ WARNING** Verify power supply and control voltages coming to the heater match the ratings printed on the heater nameplate before energizing.
- ⚠ WARNING** Heater must be installed so the minimum clearances shown in Specifications table are maintained.
- ⚠ WARNING** This heater is NOT suitable for use in hazardous locations as described by the National Fire Protection Association (NFPA). this heater has hot and arcing or sparking parts inside. DO NOT use in areas where gasoline, paint or other flammable liquids are used or stored.
- ⚠ WARNING** The mounting structure and anchoring hardware MUST BE capable of reliably supporting the weight of the heater plus mounting bracket if used. Refer to specifications table for heater weight.
- ⚠ WARNING** Heater air flow MUST be directed parallel to or away from adjacent walls.
- ⚠ WARNING** To prevent a possible fire, DO NOT block air intakes or exhaust openings in any manner. DO NOT allow foreign objects to enter grill openings as this may cause electric shock, fire or damage to heater.



**CAUTION—RISK OF ELECTRIC SHOCK
DO NOT OPEN HEATER SHELL**



KB Eco2S INSTALLATION INSTRUCTIONS




Figure 2-1

CAUTION!
Turn OFF all electrical power to install heater

DANGER



ELECTRIC SHOCK OR FIRE HAZARD

READ ALL WIRE SIZING, VOLTAGE REQUIREMENTS AND SAFETY DATA TO AVOID PROPERTY DAMAGE AND PERSONAL INJURY

Selecting a location for your heater:

The heater should be installed out of the reach of persons. The direction of air flow should not be restricted by machinery, beams, etc., and the air flow should wipe exposed walls rather than blowing directly at them. When more than one heater is used in an area the heaters should be arranged so that the air discharge of each heater supports the air flow of the others to provide best circulation of warm air.

(see air flow chart)




Hardware Needed

You will also need the following hardware, which can be purchased from your local hardware store or electrical supply house:

- adequate gauge and length of wire for your application
- proper size fuses or breakers to handle amperage
- proper wire connectors for your application
- fasteners appropriate for application that are strong enough to hold unit

For certain applications conduit may be required. Check local electrical codes. Also, if you run the wiring in conduit and wish to be able to turn the heater, be sure to purchase enough flexible conduit to allow the heater to be turned.



Mounting Height

When the airflow of the heater is directed vertically or horizontally the minimum mounting height is 6 feet.


Mounting heights depend upon building utilization and heater kW capacity.

Distance From Walls

Be sure to maintain 8" minimum clearance to walls and ceilings.

Mounting Bracket & Heater

Locate a stud in ceiling or wall and securely fasten bracket to supporting surface with 3 x 1-1/4" screws.



Attach heater to bracket with 3/8" x 1" bolt & lock washer supplied with bracket. After desired air discharge position has been determined, tighten bolt so the heater will not pivot.

Unpack & Inspect Your New Heater

Remove heater from the box and inspect it for any damage. Verify you have received the universal wall/ceiling mounting bracket.

Tools Needed


You will need the following tools to install your unit heater:

- Screwdriver - (Phillips head & slotted)
- Pliers
- Electric Drill
- Wire Cutters
- Adjustable Wrench

WARNING
 Before proceeding further with the installation of this heater, turn off the power and lock to the supply line for the heater at the main service box.


Wiring

- Step 1: Remove wiring compartment cover.
- Step 2: Remove one of the knockouts from back of unit.
- Step 3: Select power supply wire to comply with local and national electric codes using heater rating given in table 1 below. Connect wire to heater as shown in wiring diagram attached to cover. Secure power supply cable with strain-relief clamps. Connect grounding conductor to green screw.
- Step 4: Reinstall wiring compartment cover.
- Step 5: Adjust the louvers to the desired position.
- NOTE: The louvers are designed so they can not be completely closed. Do not attempt to defeat this feature - damage to the unit can result.



OPERATION

Operating Instructions



1. Push the  button, the heater will come on and heat to the default setting of 77°F.
2. Once the room temperature reaches the set point, the heater will stop running.
3. In normal operation the display will show the current room temperature.

Automatic 2-stage HIGH/LOW operation


Eco2S controller offers energy efficient 2-stage heating, automatically using the lowest wattage required to heat the room.

- During operation, when the set temperature is within 2 degrees of the room temperature the heater automatically switches to ECO mode, operating at LOW wattage.



Room Temperature Selection

- During operation, push  or  arrow buttons to set the temperature from 45°F-99°F. Hold down the UP or DOWN arrow to speed up the selection process. The LCD will go back to display room temperature after 5 seconds.


Timer Mode Selection

- During operation, press the  button 1 time, the display window will show the timer mode setup. Push the UP or DOWN arrows to set the timer from 1 hour—9 hours.

Fan Only Mode Selection

- During operation, press the  button 2 times, the display window will show H (Heat Mode) or F (Fan Only Mode). Push  to enter Fan Only mode. Push  to enter Heat Mode.

Factory Reset

- During operation, press the and HOLD the  button for 5 seconds to reset to the factory settings.

Sensor Error Code



- During operation, if the display shows E1 that indicates an issue with the sensor and the sensor needs to be replaced. Contact customer support for assistance. Press the and HOLD the  button for 5 seconds to reset to the factory settings.

Table 1

MODEL	UPC	WATTS	BTUH	PHASE	VOLTS	AMPS
KB2404-1-EC-B1	22037	4	13.5	1	240/208	16.6/14.4
KB2405-1-EC-B1	22038	5/3.3	17	1	240/208	20.8/18
KB2406-1-EC-B1	22039	6	20.5	1	240/208	25/21.6
KB2407-1-EC-B1	22040	7.5	25.6	1	240/208	31.2/27
KB2410-1-EC-B1	22042	10	34.1	1	240/208	41.6/36.1
KB2412-1-EC-B1	22043	12.5	42.7	1	240/208	52/45.1
KB2004-1-EC-B1	22045	4	13.5	1	208	19.2
KB2005-1-EC-B1	22046	5/3.3	17	1	208	24
KB2007-1-EC-B1	22048	7.5	25.6	1	208	36.1
KB2010-1-EC-B1	22050	10	34.1	1	208	48.1
KB2012-1-EC-B1	22051	12.5	42.7	1	208	60.1

Control Panel





KING ELECTRIC MFG CO · 9131 10TH AVENUE SOUTH ·
SEATTLE, WA 98108 · PH:206 762 0400 · FAX: 206 763 7738
· www.king-electric.com